HOT TUB ALGAE TREATMENT

- 1. Balance your pH and Alkalinity 1st! pH should be between 7.2 and 7.6, and Alkalinity between 80 and 120.
- 2. Turn your hot tub heater down all the way.
- 3. Remove your hot tub cover and keep it off.
- 4. Add 4 ounces of granular chlorine into your hot tub.
- 5. Run your jets on high for 10–15 minutes.
- 6. Then, turn your jets off. This water will stay in your hot tub for the next 48 72 hours. During that time, turn the jets on high for 1–2 minutes as often as you can it is best to do this at least 6 10 times per day.
- 7. After 48 72 hours, drain and refill your hot tub.
- 8. Remove your old filter and discard and replace with a NEW filter.
- 9. Test and balance your pH and alkalinity. Once your pH is between 7.2 and 7.6 and your alkalinity is between 80 and 120, begin adding bromine to your hot tub and add 1 bottle of Stain & Scale to prevent calcium build up.



HOT TUB ALGAE TREATMENT SHOPPING LIST

Granular Chlorine

pH Reducer

Alkalinity Increaser

Stain & Scale

Bromine Tabs or Frog Bromine Cartridge

