HOT TUB PURGE

- 1. Open hot tub cover and set temperature to 95 degrees.
- 2. Remove filter cartridge.
- 3. Add entire bottle of Natural Chemistry Spa Purge while jets are running.
- 4. Run jets for a minimum of 5 minutes. Some foaming is expected during the purge process if foaming becomes excessive, turn jets off.
- 5. Maintain water temperature at 95 degrees and allow hot tub to circulate overnight with the jets off.
- 6. Drain the hot tub and rinse/clean all hot tub surfaces.
- 7. Refill the hot tub and replace the filter cartridge.
- 8. Allow water to circulate for 24 hours.
- 9. Test and balance your hot tub water accordingly.



HOT TUB PURGE SHOPPING LIST

Natural Chemistry Spa Purge

pH Reducer

Alkalinity Increaser

Stain & Scale

Bromine Tabs or Frog Bromine Cartridge

